


## UNPACKING INSTRUCTIONS FOR ROSE BOUQUET <RSE-700>

- 1 With the top facing up, carefully open the cardboard box.
- 2 Remove white foam layer to expose the black inner box.
- 3 Remove the black inner box lid.
- 4 Carefully remove the whole foam-wrapped piece and place on a table.
























5 Cut the yellow tape and

very carefully remove

the first layer of foam.

